


SLIMTECH

ELECTRICAL SWITCHES
AND SOCKETS



EN
INSTALLATION AND
MAINTENANCE GUIDE

Please retain this Lusso guide for warranty,
maintenance and future reference

LUSO

LUSO

CARE GUIDE

WARRANTY REQUIREMENTS

Please pay attention to the below information.
Failure to do so will void your warranty*

- ✗ Do not use acid cleansers
- ✗ Do not use abrasive cleansers
- ✗ Do not use abrasive cloths

MAINTENANCE INSTRUCTIONS

- ✓ Dry with a soft cloth
- ✓ To remove surface marks, please use a neutral cleanser without coarse grained powder

*The consumer takes full responsibility for any damage caused by improper maintenance and using the incorrect cleaning products. Lusso cannot be held accountable for this.

INSTALLATION GUIDE

STEP BY STEP

- 1.0 Locate the fuse box that controls the power to the existing switch/socket and turn it off. Test the switch/socket to ensure no power is running.
- 2.0 Remove your existing switch/socket.
- 3.0 Take note of the connected wires, there should be at least two; one red or brown (live) and one blue or black (neutral). If your switch/socket is part of a three-way or four-way circuit, you may have additional wires.
- 4.0 Connect the wires to the corresponding terminals on the new switch/socket. Tighten the terminal screws securely or push the wires into the connectors until they click into place. Carefully fold and tuck the wires into the back box.
- 5.0 Secure the new switch/socket to the box using screws provided.
- 6.0 Push the faceplate cover over the new switch/socket until it clicks into place.
- 7.0 Return to the fuse box and turn the power back on. Check the switch/socket is functioning correctly.

If you need to remove the faceplate in the future, please insert a small flat screwdriver into the hole on the side of the switch/socket and carefully remove it.